





## 2008 Volkswagen Maintenance Schedule by Miles/Kilometers

	Miles	5	10	20	30	40	50	60	70	80	90	100	110	120
	Kilometers	8	16	32	48	64	80	96	112	128	144	160	176	180
Exhaust System – Check for damage and links				X		X		X		X		X		X
Sunroof Frame: Clean and lubricate				X		X		X		X		X		X
CSC sunroof: Clean and lubricate guide rails. (Eos)						X				X				X
CSC roof: Check for damage and function; clean wind deflector and seals. (Eos)				X		X		X		X		X		X
Convertible top: Check function and check roll-over protection with convertible top open (New Beetle Convertible)						X				X				X
Rear Spoiler: Lubricate (New Beetle)			X	X	X	X	X	X	X	X	X	X	X	X
Road test: Check kick down, braking, steering, heating and ventilation, air conditioning, power accessories and electrical systems.				X		X		X		X		X		X
Power Steering – check fluid level						X				X				X
Front Axle – check dust seals on ball joints, tie rods; check tie rods				X		X		X		X		X		X
Service Interval Display: Reset (where applicable)		X	X	X	X	X	X	X	X	X	X	X	X	X
Service Interval Display - adapt (for 10,000 mile/16,000 Km service interval only) (where applicable)			X											
Underbody- Check for damage						X				X				X
Water Separator: Drain (TDI)		X	X	X	X	X	X	X	X	X	X	X	X	X
Fuel filter: Replace (TDI)				X		X		X		X		X		X
12V starter and auxiliary battery: Check (where applicable)			X	X	X	X	X	X	X	X	X	X	X	X
Interior lights and power outlets- check						X				X				X
Turbocharger: Lubricate servo motor rods (5.0L TDI)				X		X		X		X		X		X
Diesel Particle filter: Replace (5.0L TDI)														X
Air suspension: Check for leaks and damage (Touareg)						X				X				X
Haldex clutch: Change fluid (where applicable)						X				X				X

Every 12 months, regardless of mileage (kilometers): Perform visual check of airbag system

Every 2 years, regardless of mileage (kilometers): change brake fluid and check bolting device for convertible top

Every 2 years, (for vehicles driven less than 40,000 miles (60,000 Km) in 2 years): Replace dust and pollen filter

Every 4 years, regardless of mileage (kilometers): Tire filler bottle in tire mobility set is replaced (Observe expiration date)

Every 6 years (for vehicles driven less than 60,000 miles 90,000 Km in 6 years): Change air filter element and clean housing)

Every 6 years, regardless of mileage (kilometers): change tire pressure sensors (if available)

© 2008 Volkswagen Group of America, Inc.

All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Volkswagen Group of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.

5/16/2008